Difficulty Rating
Note de difficulté
Calificación de dificultad



Installation Bulletin
Bulletin d'installation
Boletín de Instalación

IB60

08-08

Application: Application: Aplicación:

Mazda MPV | Mitsubishi Endeavor, Galant | Subaru Legacy, Outback, Tribeca | Toyota 4Runner, FJ Cruiser, Celica, Prius, Sienna



Location of filter:
Behind the glove compartment, behind the cabin filter access door on the passenger side of the vehicle

Tools:
Unknown or not required.

To remove existing filter:
1. Open the glove compartment.
2. Push in on both sides of the glove compartment releasing the glove compartment stops and swing the glove compartment down.
3. Locate the cabin filter access door and remove.
4. Remove the dirty filter and replace with clean filter.
5. Reverse steps 1-3 to complete installation.

Difficulty Rating
Note de difficulté
Calificación de dificultad



Installation Bulletin
Bulletin d'installation
Boletín de Instalación

IB60

08-08

Application: Application: Aplicación:

Mazda MPV | Mitsubishi Endeavor, Galant | Subaru Legacy, Outback, Tribeca | Toyota 4Runner, FJ Cruiser, Celica, Prius, Sienna



Emplacement du filtre :
Derrière le compartiment à gants, derrière la porte d'accès au filtre de l'habitacle du côté passager du véhicule.

Outils :
Inconnu ou non requis.

Pour enlever le filtre actuel :
1. Ouvrez le compartiment à gants.
2. Poussez sur les deux côtés du compartiment à gants afin de le libérer de ses taquets et faites-le basculer vers le bas.
3. Localisez la porte d'accès au filtre de l'habitacle puis enlevez-la.
4. Enlevez le filtre souillé et remplacez-le avec un nouveau filtre.
5. Inversez les étapes 1 à 3 afin de finaliser l'installation.

Ubicación del filtro:
Detrás de la guantera, detrás de la puerta de acceso a la caja del filtro, en el lado del pasajero del vehículo.

Herramientas:
Desconocidas o no requeridas.

Para quitar el filtro existente:
1. Abra la guantera.
2. Presione ambos lados de la guantera a fin de liberar los topes de seguridad y gire la guantera hacia abajo.
3. Localice y retire la puerta de acceso a la caja del filtro.
4. Quite el filtro sucio y cámbielo por un filtro limpio.
5. Invierta los pasos del 1 al 3 para completar la instalación.